



NOTES:

- 1) Balance the total number of Net/X-Stats between the two X1 terminal screws on the NT-SSAx/CLK
- 2) Terminate all X2 wire connections together at the NT-SSAx/CLK, X2 terminal
- 3) No more than 16 SerialStats can be wired to one NT-SSAx/CLK, X1 terminal
- 4) Use a similar quantity of Net/X-Stats on each daisy chain